

BLADDER INSTRUCTIONS (WASTE WATER)

AIRE offers two types of bladders, potable and wastewater. Wastewater Bladders are made of durable PVC fabric that is better suited for wastewater applications.

WHAT YOU NEED TO KNOW

SITE PREP

1. Level the deployment area to keep the bladder from shifting.
2. Clear out any debris that might cause damage to the bladder.

DEPLOYMENT

1. Lay out the included ground pad.
2. Centered in the prepared deployment area, unroll the bladder on top of the ground pad.
3. Position the bladder to fit your needs. (Make sure the bladder doesn't hang over the edge of the level deployment area.)



DRAGGING THE BLADDER WILL COMPROMISE ITS ABILITY TO CONTAIN WATER.

SET UP

1. Tape or apply an NSF approved sealant to any components you intend to connect to the bladder.
 - a. Note: you will need to install the breather cap.
 - b. Wrap the threads using the included Teflon tape.
 - c. Then screw the breather cap into the $\frac{3}{4}$ " port on the bladder.
2. Connect components, being careful not to damage the fabric by using too much torque.
3. Connect fill/discharge hoses, also being careful not to put too much torque on the bladder.

Breather Cap



RECOMMENDATIONS

1. Regularly check the bladder and fittings during use to identify and mitigate leaks.
2. Do not use or leave sharp objects near the bladder.
3. Keep the area around the bladder clear of debris that might attract rodents. Rodents sometimes will chew on the vinyl.
4. If using a bladder for long-term storage, check with your local water quality office to ensure compliance with local regulations on water quality, treatment and testing.
5. You may want to cover the bladder to protect it and its contents from the sun. Bladder covers work best if installed with a small air gap between them and the bladder. Protecting the bladder from UV will also help in preventing microbial growth.

TIME TO DRY & STORE

1. Drain and dry the bladder completely.
2. Remove any attached components that were installed during bladder operation.
3. Fold the bladder within its ground pad or clean tarp. Be careful not to damage or drag it.

STORAGE

1. Store the bladder in a dry area, protected from the sun and rodents.

RECOMMENDED PRODUCTS

Quick Snap Berm



Universal Spill Kit



Diversion Tubes



Need a custom size, color or design? Call 1 (800) 247-3846.

